✓ Local

✓ Safe

✓ Reliable

LPG for your home

ELGAS

Connect today 0800 435 427



SWITCH TO HASSLE-FREE GAS FROM ELGAS



ELGAS is one of the largest suppliers of LPG across Australia and New Zealand which means that we have your home LPG energy needs covered, no matter where you live.

Why ELGAS?

- Quick and easy online sign up and ordering
- Free and reliable doorstep delivery from a branch near you
- No lock-in contracts
- 24/7 telephone and online assistance

Local, Safe, Reliable.

Whether you are a property owner or renting, if you've recently moved into a home that is already connected with ELGAS LPG we make it easy to continue your gas supply with us. Simply call us on 0800 435 427 or sign up online and we'll get your account set up to ensure your gas supply is sorted.

Scan the QR code to check out our latest deals and sign up





Changing and moving to ELGAS is just as simple.

If you would like to change your LPG gas supply to ELGAS it couldn't be easier.
Simply call us on 0800 435 427 or sign up online, and once we've set up your new account you can leave the switch to us.
We'll take care of your new connection and change over your LPG cylinders.



24/7 Customer Support

We understand that you may need our support at any time of day or night. That's why our local call centres are backed up by **24/7 telephone support**, so there is always someone ready to answer your questions.



NEW TO HOME LPG? YOU ARE IN THE RIGHT HANDS!



HOW DOES LPG WORK?

LPG is stored under pressure as a liquid in a gas bottle. It turns back into a gas when you release some of the pressure by turning on your appliance.



HOW MANY LPG GAS BOTTLES DO I NEED?

Most homes use two 45kg gas bottles. As soon as one bottle runs low, call ELGAS to order a replacement – while continuing to use your second bottle.




HOW ARE THE GAS BOTTLES CONNECTED TO MY HOME?

LPG is connected by tubing (also known as 'pigtails') to a changeover valve. The changeover valve is connected to a regulator.



WHO PROVIDES THE REGULATOR, CHANGEOVER VALVE & 'PIGTAILS'?

If you're starting from scratch, a licensed gas fitter is needed to install the gas regulator, changeover valve and the 'pigtails' (tubing). ELGAS provides the gas bottles.





HOW WILL MY GAS BE DELIVERED?




ELGAS can deliver to your home by small tanker or exchange cylinders.



AUTOMATIC TANKER DELIVERY

Automatic Tanker Delivery means no calling to order gas or checking your gas bottles. We calculate your gas usage – based on historical use – and schedule your deliveries to match your needs. Our tanker truck will refill your gas bottles safely from your driveway.

We need a clear line of sight from our tanker to your gas bottles for ELGAS Easygas™ delivery.



GAS BOTTLE EXCHANGE DELIVERY

ELGAS arrives with new gas bottles to replace your empty bottles. Simply order online when one of your LPG bottles is empty. We detach and attach the gas bottles for you. Make sure you keep your contact information up to date and that we have your mobile phone number so that you can receive service and delivery alerts by text (SMS).

Home delivery and installation requires access for a hand trolley and 45kg bottles.



EasyGas is not available in all geographic areas.

Please contact your local ELGAS Customer Service Team on **0800 435 427** to confirm if EasyGas™ is available where you are.



HOW DO I KNOW HOW MUCH GAS IS LEFT?

LPG bottles are designed to be 'full' when they're at 80% capacity, or just over three quarters full. This allows for the natural expansion of the gas during warmer temperatures.



Carefully pour hot water down the side of the bottle.

If you see no line and feel no difference, then your bottle is most likely empty. Always use care with hot water.



A line of condensation should appear at the level of the gas.



If no line is apparent, run your hand down the cylinder. It will feel cool to the touch at the level of the gas.






HOW DO I CHANGE MY GAS BOTTLES?



AUTOMATIC CHANGEOVER SWITCH VALVES

Do not touch or turn the indicator.





Automatic changeover valves use a visual indicator to show when a gas bottle is empty and it has switched over to the second gas bottle.



When it turns red, that's your signal to call ELGAS for a replacement bottle.
We will deliver a full bottle and reset the indicator.



With an automatic changeover valve, you do not need to do anything. Just be sure to check your gas bottles (and visual indicator) regularly.

MANUAL CHANGEOVER SWITCH VALVES

Your gas supply will stop when a gas bottle is empty.





Turn the hand wheel on the empty gas bottle to OFF (clockwise).



Move the changeover valve lever to point towards the second (full) gas bottle.



Turn the hand wheel on the full gas bottle to ON (anti-clockwise). Call ELGAS to replace the (empty) gas bottle.



SUSTAINABILITY



ELGAS is committed to reducing greenhouse gas emissions by 38% by 2028. We are investing in new technology to reduce emissions across our operations and sourcing renewable energy for our sites.

LPG is a cleaner, lower carbon and efficient fuel for homes that are off-grid or not connected to mains natural gas and will continue to be a critical part of New Zealand's energy mix for years to come. That's why we will work with government, industry and our customers as we transition to a low emissions future.

Supporting decarbonisation

LPG can immediately support climate ambitions by delivering emission reductions of up to 50% for coal users and other heavy carbon emitting fuels such as fuel oil and diesel. LPG is a reliable back up fuel for renewable energy and off-grid applications. It is also used to dry raw bio gases such as bio-methane, so they can be utilised as renewable fuels in the future.

Leading development of renewable gas

The promise of renewable LPG, being developed as part of the global push to develop biogases such as biomethane and being distributed through an existing supply chain, offers a pathway to a zero carbon economy with no appliance upgrade costs. Our goal is to be producing 100% renewable LPG for our customers by 2040.

For more information on our sustainability commitments, visit elgas.co.nz/sustainability









WHAT IF I ALREADY HAVE GAS BOTTLES AT HOME?

• Open a new ELGAS account online and order LPG bottles when you need them. If the bottles are from another supplier, we will remove the old bottles and return them for you – at no charge.



HOW DO I MAKE SURE I DON'T RUN OUT OF GAS?

- Always order gas as soon as your first bottle runs out. Don't wait until both LPG bottles are empty or near empty.
- Check your gas bottles regularly in cold weather or when you have additional house quests.
- If you only have one gas bottle attached to your home think about adding a second gas bottle, particularly if you use it for hot water and/or heating.
- Make sure we have your mobile phone number so you receive service and delivery alerts by text (SMS).
- Let us know if you install additional appliances, especially if you are on automatic tanker delivery. We can adjust your delivery schedule to suit any additional needs.



HOW DO I PAY FOR MY LPG?

• Visit our website at elgas.co.nz/pay and choose a payment option to suit, including bPay, Direct Debit or Credit Card.



WHAT IF THE GAS ISN'T WORKING?

- Make sure the correct gas valve is turned on.
- Check to see if either gas bottle has any gas left, using the hot water test.
- If one bottle is empty, switch the manual changeover valve to your full gas bottle.
- If both bottles are empty, contact ELGAS for an urgent delivery. Make sure you tell us you need two gas bottles.



WHAT IF THERE IS A GAS LEAK?

In the unlikely event that you have a gas leak:

- Turn off the cylinder valve(s) by rotating clockwise.
- Call ELGAS Emergency Response on 0800 435 427.
- Make sure the area is well ventilated to disperse any gas.
- Remove or turn off all flames and other sources of ignition that may be nearby.

